

TMPGEnc DVD Author 3 with DivX Authoring 対応ドライブ一覧

メーカー名	ドライブ型番	ファームウェアバージョン
ACER	DVD RW 4XMax	2.21
	DVD DUAL 4XMax	—
	DVD RW 8XMax	—
Actima	CD-RW CRW4012A	—
	ARW4420	1.2
	ARW4420S	1.2
	DVD+RW ADRW-H00P	—
ALN	DVD+/-RW AL1300A	—
AOpen	CD-RW CRW1232 A/PRO	—
	CRW9420	1.2
	CRW9420S	1.2
	12X10X32 CD-RW A/P	—
	CD-RW CRW1632	—
	16X10X32 CD-RW	—
	CD-RW CRW2040	—
	20X10X40 CD-RW	—
	CD-RW CRW2440	—
	24X10X40 CD-RW	—
	CD-RW CRW3248	—
	DVRW2412PRO	—
	2.4X2.4X8 121032	—
	40X12X50 CD-RW	—
	CD-RW CRW4050	—
	48X12X50 CD-RW	—
	CD-RW CRW4850	—
	48X24X52 CD-RW	—
	CD-RW CRW4852	—
	52X24X52 CD-RW	—
	CD-RW CRW5224	—
	DVRW4416PRO	—
	4X4X8 241640	—
	52X32X52 CD-RW	—
	CD-RW CRW5232	—
	COM4824/AAH	1.04
	16X48X24X48	—
	8X8 DVD Dual AAG	—
	8X8 DVD Dual AAN	—
	8X8 DVD Dual APP	—
	DRW8800/APP	—
	COM5232/AAH PRO	1.04
	52X32COMBO	—
CRW5232/AAO PRO	1.02	
52X32CD-R/RW	—	
ASUS	CRW-4816A	1
	CRW-5224A	—
	SCB-1608	1.0B
	SCB-2408	1.0E
	CD-RW 40X12	—
	CD-RW 48X16	—
	CD-RW 48X24	—
	CD-RW 48XMAX	—
	CD-RW 52X24	—
	CD-RW 52XMAX	—

ATAPI	CD-RW 52X32	M.AD
	DVD RW 4XMax	2.21
	DVD RW DD0203	2.21
	DVD DUAL 4XMax	—
	DVD RW DD0201	2.21
	DVD RW TDD0201	—
	DVD RW 8XMax	—
	DVD RW DD0401	—
	DVD DD 2X16X4X16	G7J9
	ATAK	DVD RW DD0203
DVD RW DD0201		2.21
DVD RW TDD0201		—
DVD RW DD0401		—
BENQ	CDRW 5232X	KPEY
BTC	BCE1610IM	—
	BCE3212IM	—
	BCE4012IM	—
	BCO1612IM	—
	BCE4816IM	—
	BCO4016IM	—
	BCE5224IM	—
	BCE5224SO	—
	BCE5232IM	—
	BCE5232SO	—
CARAVELL	CDR-N820S	1.02
	CRW-8220S	—
CD-RW	CDR-4048S	—
	CDR-4048W	—
	CDR-4048SD	—
	CDR-5W48	—
	MAR-401248W	—
	MAR-401248S	—
	MAR-401248SD	—
	CDR-6S48	—
	SMART CLONE48	—
	SMART CLONE52	—
	CDR-4848S	—
	CDR-5G48	—
	CDR-5S48	—
	CDR-6K48	—
	CDR-6S52	—
	CDR-7K52	—
	CDR-7S52	—
CD-R/RW	52X24X52X	—
CDWriter	IDE1610	—
	IDE5224	—
	IDE5224SO	—
	IDE5232	—
	IDE5232SO	—
GENDYNE	522452AL	—
CNBridge	CBCO1K-48X	—
	CBRW6S-48X	—
	CBRW6K-52X	—
	CBRW6S-52X	—
	CBRW7K-52X	—
	CBRW7S-52X	—

COMBI	RW16x10/DVD	--
	RW16x8/DVD	--
	RW16x12/DVD	--
	COB-1K4816	--
COMBO	IDE1612CO	--
	IDE4016CO	--
	COB-1K4816	--
	IDE5216CO	--
	BCO5232IM	--
CREATIVE	IDE5232CO	0053
	RW6424E	1.0
	COMBO CBA820E	--
	RW4810E	--
CyberDrv	RW4811E	--
	CW089D CD-R/RW	13ZM
CYQVE	CW099D CD-R/RW	140M
	CQ8060A	1.57
	CQ7125	1.00
Delta	CQ1232	1.00
	OIP-RW2004	1.20
DGMaster	OME-W141	1.20
	DGM-241040	--
	DGM-321240	--
	DGM-401248	--
	DGM-481248	--
DVDRW	DGM-482448	--
	DRW-2S81	--
EMC	IDE1108	--
	CD-R/RW 52X24X52	--
FREECOM	DVD+/-RW4B	--
	DVD+/-RW8B	--
	DVD+/-RW8B9	--
	DVD+/-RW16B9	--
	DVD+/-RW16B8	--
	DVD+/-RW16B6	--
	DVD+/-RW16B7	--
GENERIC	CRD-RW1	--
	CRD-RW1N	--
	FREECOM32A	--
	DVD-RAM MLT01	--
	DVD RW 4XMax	2.21
	DVD DUAL 4XMax	--
	DVD RW 8XMax	--
	DVD-RAM MLT02	--
	DVD-RAM MLT03	--
	DVD-RAM MLT04	--
	DVD-RAM MLT05	--
DVD-RAM MLT06	--	
GENERICP	UJ-820P	--
	UJ-822P	--
	UJ-830P	--
	UJ-831P	--
	CD-RW GCE-8160B	--
	RW/DVD GCC-4320B	--
	DVDRAM GMA-4020B	--
	RW/DVD GCC-4480B	--

HL-DT-ST

RW/DVD GCC-4481B	—
RW/DVD GCC-4482B	—
RW/DVD GCC-4483B	—
RW/DVD GCC-4484B	—
RW/DVD GCC-4240N	0111
RW/DVD GCC-4241N	—
RW/DVD GCC-4520B	1.00
DVDRAM GSA-4040B	A100
CD-RW GCE-8480B	1.06
CD-RW GCE-8481B	1.02
CD-RW GCE-8523B	1.03
DVDRAM GSA-4080B	—
DVDRAM GSA-4081B	—
DVDRAM GSA-4082B	—
RW/DVD GCC-4521B	—
CD-RW GCE-8526BN	1.00
DVDRAM GSA-4080N	1.00
DVDRAM_GSA-4080N	—
DVDRAM GSA-4120B	N0B7
DVDRAM GSA-4160B	A301
DVDRAM GMA-4080N	—
DVDRAM GSA-4163B	—
RW/DVD GCC-4522B	1.00
DVDRAM GSA-4165B	
DVDRAM_GSA-4165B	—
DVDRAM GSA-4167B	
DVDRAM_GSA-4167B	
DVDRAM GSA-4082N	—
DVDRAM_GSA-4082N	—
DVDRAM GSA-4168B	—
DVDRAM GSA-H10N	—
DVDRAM_GSA-H10N	—
DVDRAM GSA-H10A	—
DVDRAM_GSA-H10A	—
DVD RAM_GSA-T10N	—
DVDRAM GSA-H12N	
DVDRAM GSA-H12L	UJ03
CD-Writer cd16e	—
CD-Writer+M820	1.13
DVD Writer 100j	—
DVD Writer 200j	—
CD-Writer+ 8200	1.0f
CD-Writer+ 8290	1.3c
CD-Writer+ 9200	1.0e
CD-Writer+ 9100	1.0c
CD-Writer+ 9500	1.0e
CD-Writer+ 9600	1.0a
CD-Writer+ 9100c	2.0h
CD-Writer+ 9500b	1.3
CD-Writer cd24p	—
CD-Writer cd16n	—
CD-Writer cd16r	—
CD-Writer cd12n	—
CD-Writer cd12d	—
CD-Writer cd4f	—
DVD Writer 300n	—

HP

	DVD Writer 400n	—
	DVD Writer 420n	—
	DVD Writer 520n	—
IBM	CDRW-USB2	M1B1
IDE-CD	R/RW 4x4x24	—
	R/RW 4x4x32	—
	R/RW 8x4x32	—
	R/RW 12x8	—
	R/RW 12x8x32	—
IDE-DVD	R/RW 12x10	—
	DVDRW6001	—
	DVDRW6002	—
IMATION	IMW040420	1.20
IO DATA	CDRW-SX64	—
	CDRWD-RX1210J	1.05
	CRWD-RX20J	—
IOMEGA	ZIPCD3840INT-A	—
	CDRW9600INT	—
	CDRW64896INT-B	—
	ZIPCD 4x650	—
	ZIPCD 650 USB	—
	ZIPCD1024INT-A	—
	CDRW27648INT-B	—
	CDRW55292EXT3-B	—
	CDRW55292INT-B	—
	CDRW55296INT-B	—
	CDRW5529DEXT1-B	—
	CDRW5529FEXT1-B	—
	CDRW64892EXT3-B	—
	CDRW86592EXT3-B	—
	DVDRW4216INP-A	—
	DVDRW4216IND-A	—
	DVDRW4216E2D-A	—
JLMS	COMBO LSC-24081	—
	COMBO LSC-24081M	—
	COMBO LSC-24081S	—
	LTC-48161K	—
JVC	XR-W4082	1.37
	XR-W4080S JVC製品型番: ・XR-S4224W ・XR-K4224Wのみ対応	—
	XR-RW2224	2.50
	XR-RW4424	1.09
	RW4224	1.37
LACIE	CD-BP12432S	2.17
	CDBP-241040A	—
	CDBP-321040A	—
	CDBP-401240A	—
	CDR-RW12432S	—
	CDRW-BOOSTER	1.07
LG	CED-8042B	—
	CED-8083B	1.05
	CED-8080B	1.11
	CED-8120B	—
	LTR-0841	MS0S

LITE-ON	LTR-12101B	—	
	LTR-16102B	OS06	
	LTR-24102B	—	
	LTR-32123S	—	
	LTR-32123H	—	
	LTR-32102S	—	
	LTR-32102H	—	
	LTR-3248MH	—	
	LTR-40125S	—	
	LTR-40125W	—	
	LTR-40126S	—	
	LTR-40126H	—	
	LTR-48125W	—	
	LTR-48126S	—	
	LTR-48246S	—	
	LXR-32122	—	
	LXR-32122A	—	
	LXR-32122B	—	
	LXR-32122C	—	
	LXR-40122	—	
	LXR-40122A	—	
	LXR-40122B	—	
	LXR-40122C	—	
	LTR-52246K	—	
	LTR-52246S	—	
	LTR-48125G	—	
	LTR-48246K	—	
	LTR-52326K	—	
	LTR-52326S	—	
	LTR-52327K	—	
	LTR-52327S	—	
	COMBO LTC-48161H	KH0F	
	COMBO SOHC-4832K	—	
	COMBO SOHC-5232K	—	
	DVDRW SOHW-812S	—	
	CD-RW SOHR-5238S	4V1J	
	COMBO SOHC-5235K	LK04	
	COMBO SOHC-4836K	SK01	
	COMBO SOHC-5236K	RK01	
	CD-RW SOHR-5239S	2S03	
	MAD DOG	MD-8XDVD9-PM	—
		MD-16XDVD9	—
		MD-16XDVD9A2	—
		MD-16X3DVD9-8X	—
		MD-16X2DVD9-8X	—
MD-16XDVD9A4		—	
MAG	CD-R/RW 52X24X52	—	
	CD-R CW7501	2.00	
	CD-R CW7502	4.05	
	CD-R CW7503	—	
	CD-RW CW7585	1.04	
	CD-RW CW7586	—	
	CD-RW CW8571	—	
	CD-RW CW7121	AH.36	
	CDDRW01	1.13	
	CDDRW02	—	

CDRRW03	--
CDRRW04	--
CDRRW05	--
CDRRW06	--
CDRRW07	--
CDRRW09	--
UJDA310	1.12
UJDA320	--
UJDA330	--
UJDA710/CDRCB01	--
UJDA720	--
UJDA340	--
UJDD410	--
DVD-RAM LF-D310	--
DVD-RAM SW-9501	--
UJDA360	--
UJDA730/CDRCB02	--
CDRRW10	--
CD-RW CW8572	--
DVD-RAM SW-9571	--
DVD-RAM SW-9581	
DVD-RAM SW-9581N	
DVD-RAM LF-D521	--
UJDD420	--
UJDA740	1007
DVD-RAM UJ-810	--
UJ-811	--
DVD-RAM UJ-811	--
DVD-RAM UJ-815	--
DVD-RAM LF-P567	--
UJDA747	--
CD-RW CW-8122	--
UJDA745	--
UJDA750	--
DVD-RAM SW-9572	--
DVD-RAM SW-9582	
DVD-RAM SW-9582N	
CDRCB03	1504
CDRCB04	1500
CD-RW CW-8123	--
UJDA755	--
UJDA757	--
UJ-810	--
DVD-RAM UJ-812	K1A5
DVD-RAM UJ-825S	DZK2
DVD-RAM UJ-813	--
DVD-RAM UJ-820S	A031
DVD-R UJ-825	--
DVD-RAM UJ-825	--
UJ-825/UJ-825D	--
UJDA760	1002
DVD-RAM LF-P667	1.00
UJDA750cDVD/CDRW	--
UJDA750FDVD/CDRW	
UJDA755cDVD/CDRW	--
UJDA755yDVD/CDRW	

MATSHITA
(Panasonic)

UJDA755zDVD/CDRW	
UJDA760cDVD/CDRW	—
UJDA760eDVD/CDRW	
DVD-RAM SW-9573	—
DVD-RAM SW-9583	
DVD-RAM LF-M721	
DVD-RAM LF-M760	
DVD-RAM SW-9573S	—
DVD-RAM SW-9583A	
DVD-RAM SW-9583S	
SW-9573/SW-9583	—
SW-9573D/SW-9583D	—
DVD-RAM UJ-820	—
DVD-RAM UJ-820c	
UJ-820	—
UJ-820D	—
DVD-RAM UJ-822S	—
DVD-RAM UJ-822	1000
DVD-RAM UJ-822c	
UJ-822	—
UJ-822D	—
DVD-RAM UJ-830S	—
DVD-RAM UJ-830c	
DVD-RAM UJ-830	—
DVD-RAM UJ-830cc	
UJ-830	—
UJ-830D	—
DVD-R UJ-835	—
DVD-RAM UJ-822Sa	—
DVD-RAM UJ-822Se	
UJ-822Da	—
DVD+RW UJ-822D	
DVD-RAM UJ-823S	—
DVD-RAM UJ-830Sa	—
DVD-RAM UJ-830Se	
DVD-RAM UJ-835	—
DVD-RAM UJ-835A	—
DVD-RAM UJ-835S	
UJ-812	—
UJ-813	—
UJ-830Da	—
UJ-835	—
UJ-835D	—
UJDA760aDVD/CDRW	—
UJDA765 DVD/CDRW	
UJDA765aDVD/CDRW	—
UJDA765cDVD/CDRW	
DVD-RAM LF-P767	1006
DVD-RAM UJ-831S	
DVD-RAM UJ-831Sa	—
DVD-RAM UJ-831Se	
UJ-831D	—
UJ-831Da	
CDRCB05	1003
DVD-RAM UJ-840S	
DVD-RAM UJ-840Se	—

DVD-RAM UJ-845A	—
DVD-RAM UJ-845S	—
DVD-R UJ-845	—
UJ-840D	—
DVD-RAM SW-9585	—
UJDA770 DVD/CDRW	1001
CD-RW CW-8124	DZ0E
CDRCB06	—
DVD-RAM SW-9584	—
DVD-RAM SW-9584A	—
DVD-RAM SW-9585A	—
DVD-RAM SW-9585S	—
SW-9584D	—
UJ-845D	—
DVD-RAM UJ-846S	—
DVD-RAM UJ-846A	—
DVD-RAM UJ-846	—
DVD-R UJ-846	—
UJDA769	—
DVD-RAM SW-9574	—
DVD-RAM SW-9574A	—
DVD-RAM SW-9574S	—
DVD-RAM LF-M821	—
DVD-RAM LF-P867	—
DVD-RAM UJ-841S	—
DVD-RAM LF-M860	—
DVD-RAM UJ-842S	1006
DVD-RAM UJ-832S	—
UJ-832D DVD/CDRW	—
DVD-RAM UJ-833S	—
DVD/CDRW UJDA775	—
DVD-RAM SW-9586	BZ50
DVD-RAM UJ-850S	—
DVD-RAM SW-9587S	—
DVD-RAM SW-9587A	—
DVD-RAM SW-9587	—
BD-MLT SW-5582	—
DVD-RAM LF-P967	—
DVD-R UJ-85J	—
DVD-RAM UJ-85JA	FONO
DVD-RAM UJ-85JS	FONO
BD-MLT SW-5582A	—
BD-MLT LF-MB121	—
BD-MLT UJ-210S	—
DVD-RAM LF-P968	—
UJDA770 DVD/CDRW	—
UJ-857F	—
DVD-R UJ-857	—
DVD-R UJ-857D	—
DVD-RAM UJ-852c	—
DVD-RAM SW-9590A	—
DVD-RAM SW-9590	—
DVD-RAM SW-9576S	—
DVD-RAM UJ-844S	—
DVD-RAM UJE844S	—
UJDA775 DVD/CDRW	—

Maxell	MCD-RW4812-48	—
	MCD-RW4824-48	—
MELCO	CDRW-S4224	—
Memorex	CD-RW 12432S	1.07
	CDRW-4420	1.20
	CDRW-4420s	1.20
	CD-RW8220S	—
	TwelveMAXX 1032A/P	—
	48MAXX 1248AJ	—
	48MAXX 2448AJ	—
	DVD+R/RW 2.4X8AA	—
	52MAXX 2452AJ	—
	52MAXX 3252AJ	—
	DVD+/-RW True8Xn	—
DVD16+/-DL4RWnD2	—	
Mitsubishi	CDRW4420	1.20
	CDRW4420a	1.20
MITSUMI	CR-2802TE	1.3C
	CR-4802TE	1.4D
	CR-4804TE	2.2C
	CR-4805TE/CR-48X5TE	1.7A
	CR-4808TE/CR-48X8TE	1.1A
	CR-48X9TE	1.0C
	CR-48XATE	1.0A
	CR-48XCTE	1.0B
	CR-48XETE	—
	DW-7801TE	—
	DW-7802TE	—
	CR-48XGTE	—
	DR-6800TE	—
	MSI	CD-RW CR48
CD-RW CR52		—
	ODX658	1.0k
	NR-7500A	1.06
	NR-7700A	—
	NR-8500A	1.4
	NR-8400A	1.2
	NR-7800A	1.3
	CD-RW NR-7800A	—
	NR-7800B	—
	NR-7900A	—
	NR-9100A	1.11
	CB-2100A/CB-2100A_NE	—
	NR-9200A	2.01
	DVD RW ND-1200A	—
	DVD RW ND-1300A	—
	DVD+RW ND-1000A	—
	DVD+RW ND-1100A	—
	DVD-RW ND-1300M	—
	NR-9300A	1.12
	NR-9300A_S	—
	DVD+RW ND-5100A	1.07
	DVD RW ND-1200AD	—
	DVD+RW ND-2100A	1.11
	DVD+RW ND-2100AD	—
	CD-RW NR-9400A	r804

NEC	DVD_RW ND-2300A	—	
	DVD_RW ND-2500A	1.05	
	DVD_RW ND-2500A2	1.03	
	DVD_RW ND-5500A	—	
	DVD_RW ND-2510A	2.03	
	CDRW/DVD CB1100A	tb01	
	DVD+-RW ND-2510A	—	
	DVD+RW ND-3100A	—	
	DVD+RW ND-3100AD	—	
	DVD_RW ND-3500A	—	
	DVD_RW ND-3500AD	—	
	DVD_RW ND-3500AG	—	
	DVD+RW ND-6050A	—	
	DVD+RW ND-6100A	—	
	DVD+-RW ND-6450A	—	
	DVD+-RW ND-6500A	—	
	DVD+-RW ND-3450A	—	
	DVD_RW ND-3520A	1.21	
	DVD_RW ND-3521A	—	
	DVD+-RW ND-3530A	—	
	DVD_RW ND-3530A	1.21	
	DVD_RW ND-3520AW	3.20	
	DVD_RW ND-3540A	—	
	DVD_RW ND-3540B	—	
	DVD_RW ND-6650A	—	
	DVD+-RW ND-6650A	—	
	DVD_RW ND-4550A	1.24	
	DVD_RW ND-4551A	—	
	DVD_RW ND-3550A	—	
	DVD_RW ND-3551A	—	
	DVD_RW ND-7550A	—	
	DVD_RW ND-7551A	—	
	DVD_RW ND-3570A	1.11	
	DVD_RW ND-3571A	—	
	DVD_RW ND-4570A	1.02	
	DVD_RW ND-4571A	1-02	
	DVD_RW ND-7551B	—	
	Norcent	RWJ-481S	—
		RWJ-482S	—
		RWJ-483S	—
OLYMPUS	S-DVD-100	—	
OPTI	DVD RW 4XMax	2.21	
	DVD DUAL 4XMax	—	
	DVD RW 8XMax	—	
Optiarc	DVD RW AD-7170A	—	
	DVD RW AD-7173A	—	
	DVD RW AD-5170A	—	
	DVD RW AD-5173A	—	
	DVD RW AD-7540A	—	
	DVD RW AD-7543A	—	
	DVD RW AD-5540A	—	
	DVD RW AD-5543A	—	
	DVD+-RW AD-5540A	—	
	DVD RW AD-7543B	—	
	CD-RW CRX880A	—	
DVD RW AD-5630A	—		

	DVD RW AD-5633A	—	
	DVD RW AD-7630A	—	
	DVD RW AD-7633A	—	
	DVD RW AD-7170S	—	
	DVD RW AD-7173S	—	
	DVD RW AD-5170S	—	
	DVD+-RW AD-5170S	—	
	DVD RW AD-5173S	—	
	DVD RW AD-5540B	—	
OPTORITE	DVD RW DD0203	2.21	
	DVD RW DD0201	2.21	
	DVD RW TDD0201	—	
	DVD RW DD0401	—	
PHILIPS	ReWritable-2 × 2 × 6	2.00	
	228CDRW	—	
	428CDRW	1.4D	
	4424CDRW	2.2C	
	8432CDRW	1.7A	
	16840 CDRW	1.1A	
	241240 CDRW	1.0C	
	321240 CDRW	—	
	CDRW3210S	—	
	CDD5101	—	
	401240 CDRW	—	
	401248 CDRW	—	
	CDD4801	—	
	DVD+RW-D01	—	
	DVDRW1208	—	
	DVD6002	—	
	DVDRW228	—	
	DVD+RW-D02	—	
	CDRW48P	—	
	DVD+RW-D28	—	
	DVD6001	—	
	CDRWDVD1610	—	
	CDRWDVD1612	—	
	CDRW3212S	—	
	CDRW4012P	—	
	CDRW2010	—	
	CDD4851 CD-R/RW	—	
	PCRW1208	—	
	PCRW1208JR	—	
	PCRW1208MR	—	
	PCRW1208UE	—	
	PCRW804	—	
	PCRW404	—	
	PCRW406	—	
	CDD4201 CD-R/RW	—	
	DVDRW416N	—	
	CDD7052	—	
	SDVD6004	—	
	DVD8631	BB03	
		DVR-103	1.40
		DCR-111	1.00
		DVR-104	1.20
		DVR-105	—

PIONEER	DVR-K11	—
	DVR-106D	1.03
	DVR-K12D	—
	DVR-107D	1.03
	DVR-K12AS	—
	DVR-K13	—
	DVR-K13AS	—
	DVR-108	—
	DVR-K04	—
	DVR-K14	—
	DVR-K04L	—
	DVR-K14L	—
	DVR-109	—
	DVR-K15	1.06
	DVR-K16	—
	DVR-K16F	1.33
	DVR-110	1.37
	DVR-110D	—
	DVR-K06	—
	DVR-K16L	—
	DVR-111	—
	DVR-111L	—
	DVR-111D	—
	DVR-K16A	—
	DVR-112	—
	DVR-112D	—
	DVR-112L	—
	DVR-112C	—
	DVR-K16M	—
	DVR-K17	—
DVR-212	—	
DVR-212D	—	
PLEXTOR	PX-R412C	1.07
	PX-R820T	—
	PX-W4220T	1.02
	PX-W8220T	—
	PX-W8432T	—
	PX-W124TS	—
	PX-W1210S	—
	PX-W1210A	—
	PX-W1610A	—
	PX-W2410A	—
	PX-W4012A	—
	PX-320A	—
	PX-S88T	—
	PX-W4824A	—
	PX-S2410T	—
	PX-W4012S	—
	DVDR PX-504A	—
	CD-R PREMIUM	1.01
	PX-W5224A	—
	DVDR PX-708A	—
	DVDR PX-704A	—
	DVDR PX-712A	—
	DVDR PX-716A	1.06
	DVDR PX-750A	—

	DVDR PX-751A	--
	DVDR PX-755A	--
	DVDR PX-760A	--
POLAROID	BurnMAX52	--
	BurnMAX52EX	--
	BurnMAX52EX SO	--
	BurnMAX52SO	--
	48X CD-RW DRIVE	--
PROVIEW	CD-R/RW 52X24X52	--
Q-lity	ECW-043	1.0a
QPS	CRD-BP1500P	--
	CRD-BPO1700P	--
	QPSCRD-BP1600P	--
QSI	SBW-081	--
	SBW-161	--
	SBW-241	--
	SBW-242	--
	SBW242U	--
	CDRW/DVD SBW242B	UK54
	CDRW/DVD SBW242C	UX81
R-QUEST	TRUECOPY40A	--
RICOH	RO1420C	1.60
	MP6200/MP6201	1.13
	MP7040S/RW7040S	1.20
	MP7040A/RW7040A	1.20
	MP7060S/RW7060S	1.00
	MP7060A/RW7060A	1.00
	MP7063A/RW7063A	--
	MP7080A/RW7080A	1.00
	MP7083A/RW7083A	--
	MP7120A/RW7120A	--
	MP7122SE	--
	MP7125A/RW7125A	--
	MP8040S	1.13
	RW8040A	1.12
	MP9060/RW9060	1.00
	MP9120/RW9120	--
	RW8080A	--
	MC104S/RW104S	--
	MP7200A/RW7200A	--
	MP7163A/RW7163A	--
	MP9200/RW9200	--
	MP5120/RW5120	--
	MP5125/RW5125	--
	MP7320A/RW7320A	--
	MP7400A/RW7400A	--
	MP5240/RW5240	--
	MP8160/RW8160	--
	DVD+RW MP5163AN	--
	DVD+RW MP5240A	--
	DVD+RW RW8165	--
	DVD+RW MP5308D	--
	DVD+RW MP5316DA	--
	DVD+RW MP5316DAD	--
DVD+RW MP5316DAG	--	
	DVD+RW/+R DRIVE	--

RIDATA	DVD+RW DRIVE	—
	DVD RW 4XMax	2.21
	DVD DUAL 4XMax	—
	DVD RW 8XMax	—
SAF	CD-R8020	1.02
	CD-RW12432	1.07
	CD-RW8220	—
SAMSUNG	SW-207F	—
	SW-408B	—
	SM-304B	BN10
	SM-308B / SM-308N	BS03
	SW-216B	—
	DVD-MULTI SRT03B	—
	SW-240B	—
	SM-348B	—
	SM-352B	t801
	SW-252B	R701
	DVD R/RW SR-W04B	—
	CDRW/DVD SM-352F	T903
SANYO	CRD-R800S	1.02
	CRD-RW1	—
	CRD-RW2	1.07
	CRD-BP2	2.17
	CRD-BP3	1.03
	CRD-BP4	—
	CRD-BP5	—
	CRD-SBP15A	—
	CRD-BP900	—
	CRD-BP1300	—
	CRD-BP1400	—
	CRD-BP1500 /BP1500U	—
	CRD-BP1600	—
	CRD-BP1700	—
	CRD-BP1700U	—
	CRD-BP1800P	—
	CRD-BPDV2	2.21
	CRD-BPDV3	—
SHARK	CDRW1610IM	—
Slimtype	COMBI LSC-24081	—
	COMBI LSC-24081S	—
	COMBI LSC-24101	—
	COMBI LSC-24121	—
	COMBO LSC-24081	—
	COMBO LSC-24081M	—
	COMBO LSC-24081S	—
	COMBO LSC-24101	—
	COMBO LSC-24121	—
	XJ-SC241	—
	XJ-SC241M	—
	DVDRW SDW-431S	M7S3
	DVD+RW SDW-421S	LS07
	DVDRW SOSW-852S	PV86
	DVDRW SSM-8515S	GS01
Smart & Friendly	CD-RW4420J5	—
	CRX110E	1.0b

SONY

CRX100E	1.0g
CRX120E	1.0j
CRX140S	1.0P
CRX140E	1.0h
CRX160S	1.0a
CRX160E	1.0a
CRX700E	1.0f
CRX75L	—
CRX168E	—
CRX175E2	—
CRX175A	—
CRX175A1	—
CRX85A	—
CRX1611	—
CRX200E	—
CRX185E1	—
CRX185E3	—
CRX195E1	—
CRX195E4	—
DRU-120A	—
CRX810E	—
CRXP-90MU	—
CRX205E1	—
CRX210E1	—
CRX215E1	—
CRX820E	—
MPD-AP20U	—
DRU-500A	1.0c
DW-U10A	—
CRX220E1	—
CRX220E2	—
DW-U12A	—
CRX216E	—
CRX225E	QYT3
CRX300E	KYT3
CRX217E	—
CRX230E	—
DW-U14A	—
CRX950E	1.5a
CRX230E5	—
DRU-510A	—
DW-U50A	1.0a
CD-RW CRX320E	NYT3
DVD RW DRU-530A	—
DVD RW DW-U18A	UYTP
CD-RW CRX230ED	—
DVD RW AW-G170A	—
DVD RW AW-G173A	—
DVD RW AW-Q170A	—
DVD RW AW-Q173A	—
DVD RW AW-G540A	—
DVD RW AW-G543A	—
DVD RW AW-Q540A	—
DVD RW AW-Q543A	—
DVD RW AW-Q630A	—
DVD RW AW-Q633A	—

	DVD RW AW-G630A	—
	DVD RW AW-G633A	—
	DVD RW AW-Q170S	—
	DVD RW AW-Q173S	—
	DVD RW AW-G170S	—
	DVD RW AW-G173S	—
TDK	CDRW121032A	—
	CDRW161040X	—
	CDRW241040X	—
	CDRW321040X	—
	CDRW401240X	—
	CDRW401248UEX	—
	CDRW8824T	—
	CDRW5200B	—
	CDRW5201B	—
	DVDRW0404N	—
	DVDRW420N	—
	CDRW481248B	—
	CDRW482448B	—
	CDRW482448AID	—
	DVDRW880N	—
	DVDRW840	—
	DVDRW882N	—
DVDRW1616N	—	
DVDRW1616EX	—	
TEAC	CD-R50S	1.0E
	CD-R55S	1.0E
	CD-R56S	1.0J
	CD-R58S	1.0J
	CD-P520E	1.0K
	CD-W24E	—
	CD-W28E	1.1A
	CD-W54E	1.04
	CD-W58E	1.0A
	CD-W512S	—
	CD-W512E	—
	CD-W512EB	—
	CD-W516EB/W516EC	—
	CD-W524E	—
	CD-W540E	—
	DW-28E	1.0A
	CD-W216E	1.0A
	CD-W224EA	1.0A
	DW-224E	1.0A
	DV-W50E	—
	CD-W548E	1.05
	CD-W552E	1.05
	DV-W22E	1.ta
	DV-W50D	—
	DW-548D	K4H1
	CD-W552G	Q4S2
	DW-224E-A	V.4A
	DV-W58D	1.03
	DV-W58G-A	—
	DW-552G	—
	DV-W24E	—

TEAC

DV-W24EP	--
DV-W24ES	--
DV-W24EW	--
DV-W28E	--
DV-W28EP	--
DV-W28EW	--
CD-W552GB	--
DW-552GA	--
DV-W28EA	--
DW-224E-C	--
DV-W516E	1.0C
DV-W28EAD	1.0A
DV-W28EBF	--
DV-W28SL	--
DW-224E-R	--
DV-W28SLA	--
DW-224SL-R	--
DV-W28ECW	--
DV-W28EC	--
DV-W28ECT	--
DW-224E-V	--
DW-224E-VN	--
DW-224E-CN	--
DV-W28SLCW	--
TEAC DV-W28ECF	
TEAC DV-W28ECS	
TEAC DV-W28SLC	
TEAC DV-W28SLCF	--
TEAC DV-W28SLCT	
TEAC DV-W28ECTF	
TEAC DV-W28SLCTF	
IPC5025A	--
SD-R1002	1034
SD-R2002	--
SR-C8002	--
SD-R2102	--
SD-R1102	--
SR-C8102	1008
SD-R1202	--
SDR1202F/SDR1202N	--
SD-R2212	1013
SD-R2312	1001
SD-R5002	1030
SD-R2412	1006
SD-R1312	1010
SD-R5112/SDR5112N	1M03
SD-R6112/SDR6112N	--
SD-R9012	1006
SD-R2512	1006
ODD-DVD SDR1412T	1T10
SD-R6012	1033
SD-R5112/SDR5112N	1M03
SD-R6112/SDR6112N	--
SD-R9012	1006
SD-R2512	1006
ODD-DVD SDR1412T	1T10

TOSHIBA

	ODD-DVD SDR1412N	--
	ODD-DVD SD-R6352	--
	ODD-DVD SD-R6372	1004
	ODD-DVD SD-R5272	--
	DVD-ROM SDR2512N	1N21
	CDW/DVD SD-R1612	--
	CD/DVDW SD-R5372	TU53
	CD/DVDW SD-R6472	--
	CDW/DVD SD-R2612	TU30
	CDW/DVD SDR2612C	--
	CDW/DVD SDR1712C	--
	CD-R/RW SR-M8102	TP00
	CD-R/RW SRM8202C	TP00
	DVDW/HD TS-L802A	--
TRAXDATA	CDRW522452plus	--
	CDRW4424 PLUS	--
	CDRW4432 PLUS	--
	CDRW-5224E	--
	CDRW-5224E SO	--
TSSTcorp	CDW/DVD TS-H492A	TB50
	CDW/DVD TSH492AN	--
	CD/DVDW TS-H552A	--
	CD/DVDW TS-L532A	TS50
	CDW/DVD TS-L462A	TS30
	CDW/DVD TS-L462C	--
	CDW/DVD TSL462CN	--
	CD/DVDW TS-L532R	--
	CD/DVDW TS-L532S	--
	CDW/DVD TS-H492C	--
	CDW/DVD TSH492CN	--
	CD-R/RW TS-H292A	TP00
	CD-R/RW TS-H292C	TP00
	CD/DVDW TS-L632D	T100
	CD/DVDW TS-H653A	--
CD/DVDW TS-H652D	--	
CDW/DVD TS-L462D	--	
VERBATIM	241040AL	--
	321040AL	--
	401248AL	--
	481248AL	--
	482448AL	--
	522452AL	--
WAITEC	MEGALUS	--
	STORM32	--
	STORM40	--
	SFINX16	--
	SAURUS	--
	SHUTTLE	--
	WT2444EI	--
	WT3244EI	--
WDC	WDC12432SS	1.07
WPI	CDRW-4424	T2.0
	CDR200/CDR400	1.0k
	CRW2216E/CRW4416E	1.0e
	CRW4260	1.0f
	CRW4416S	1.0e

YAMAHA

CRW6416S	1.0b
CRW8424S	—
CRW8424E	—
CRW8824S	—
CRW8824E	—
CRW2100E	—
CRW2100S	—
CRW2200E	—
CRW2200S	—
CRW3200E	—
CRW3200S	—
CRW-70	—
CRW-F1E	1.0d
CRW-F1S	1.0d